

Changing Hands on Bite Pedestal

(Bite)



Changing Hands




Firstly you would need to remove the lock. If you open the lid you will see this is held in with two screws which if you remove the lock will come away.




There is a rubber bung at the front and back of the side opening. Remove these by pulling away from the unit



At the back of unit there are 2 screws on either side. Using an appropriate screwdriver remove these. Its best to leave these inside the unit so as not to lose them.




Remove the two top box bumpers at the back of the unit. Take care removing the bumper at the bottom of the lid as the hinge damper locates inside



Remove the lid by sliding it towards the back releasing the front hinge and then lift up and away from the unit



Locate the lid on the other side on the top box and slide the hinge damper into the hole at the front of the unit



Reattach the two bumpers to the back of the unit. Take care when inserting the hinge damper into the bumper below the lid



Re-insert the 2 screws at either side of the back of unit to secure the bumpers in place.



Refit the lock to the open side of the unit and refit the rubber bungs into front and back.